

Target:





Usage: Cleaning product

Type of ink: Any types of ink

For daily cleaning of inking unit, doctor blade chambers,

spare parts...

Aspect: Colorless liquid

30 liters jerrican Packaging:

Shelf life: 24 months

How to use: Product ready for use - Do not dilute

Ideal use temperature at 35°C

Directions of use: Always read the product label on the packaging and the

SDS (Safety Data Sheet)

- Our SDS are available on request -

Hand cleaning or with a fountain

• Apply product directly on dirty part. Leave on for a few minutes

• Brush the surface with adapted RECYL brush

• Rinse with clear water. Change the rinse water frequently

Cleaning in washing machine (Simplex or Cliché Cleaner type)

• Refer to the operating instructions of the machine

• Fill up the tank

• Rinse with clear water. Change the rinse water frequently

• Wash out the saturated liquid with other cleaning effluents

Food sector: Product certified compatible by EuPIA guide

(European Printing Ink Association)

UFI: U110-A06T-K00Q-3WGC

Version February 2025